

Make sure you test fit these exhaust components <u>BEFORE</u> any cutting, welding or unnecessary bending is done. Once modified, the components of the system are **NOT RETURNABLE**.

If you are unsure of the proper installation procedures or fitment, please contact a qualified exhaust shop or call our tech lines toll free at 800-421-3890 or visit our installation gallery at: www.pypesexhaust.com/install

One of our experienced exhaust techs will be glad to assist you in any way. Thanks and enjoy you new...

Pypes Performance Exhaust!

SCROLL DOWN FOR INSTRUCTIONS



TGF10E/ TGF20E

Thanks for purchasing Pypes Performance Exhaust 409 SS Pontiac splitter Adapters



<u>TGF20E</u>: These adapters are designed to allow EVT10 Pontiac splitter tip to be installed on Pypes exhaust <u>SGF70</u> system. The kit includes (2) adapter pipes with the factory style spoon hangers and (2) HVC50 U bolt clamps. welding the extension to the tailpipe can be done with a standard mig welder. Cutting of your existing tailpipes may be required for the splitters to exit properly on your vehicle. Simply cut the driver and passenger side tailpipes just above the rear hanger spoon, slide the TGF20E expanded portion on to the tailpipes and clamp using the HVC50 U bolt clamps. The spoon on the new extension will be your rearhanger.

<u>TGF10E</u>: These adapters are designed to allow EVT10 Pontiac splitter tip to be installed on Pypes exhaust <u>SGF11</u> system. The kit includes (2) adapter pipes with the factory style spoon hangers and (2) HVC50 U bolt clamps. welding the extension to the tailpipe can be done with a standard mig welder. Simply remove your rear portion of the tailpipes and replace with these adapters. Slide the clamps on first! Install the adapter spoons into the rubber hangers. Install your tips, adjust the position and clamp down the system.